



D Bedienungsanleitung

Vielen Dank, dass Sie sich für ein Ideenwelt Produkt entschieden haben!

Nehmen Sie sich Zeit und lesen Sie die folgenden Anweisungen und Hinweise zunächst ganz durch. Bewahren Sie diese Bedienungsanleitung anschließend an einem sicheren Ort auf, um bei Bedarf darin nachschlagen zu können. Sollten Sie das Gerät veräußern, geben Sie diese Bedienungsanleitung an den neuen Eigentümer weiter.

1. Sicherheitshinweise

- Verwenden Sie das Produkt ausschließlich für den dazu vorgesehenen Zweck.
- Schützen Sie das Produkt vor Schmutz, Feuchtigkeit und Überhitzung und verwenden Sie es nur in trockenen Umgebungen.
- Beim Einsatz des Produktes im Straßenverkehr gelten die Vorschriften der StVZO.
- Lassen Sie das Produkt nicht fallen und setzen Sie es keinen heftigen Erschütterungen aus.
- Halten Sie Kinder unbedingt von dem Verpackungsmaterial fern, es besteht Erstickungsgefahr.
- Entsorgen Sie das Verpackungsmaterial sofort gemäß den örtlich gültigen Entsorgungsvorschriften.
- Nehmen Sie keine Veränderungen am Produkt vor. Dadurch verlieren Sie jegliche Gewährleistungsansprüche.

2. Montage



Warnung – Verletzungsgefahr

- Lassen Sie sich auf der Fahrt mit einem Kraftfahrzeug oder Sportgerät nicht durch Ihr Produkt ablenken und achten Sie auf die Verkehrslage und Ihre Umgebung.
- Das Produkt ist nicht für die Montage an Karbonanteilen (z.B. Lenker) vorgesehen. Karbonanteile können durch die Klemmung beschädigt werden, brechen und so schwere Unfälle und Verletzungen verursachen!



Hinweis

- Wenden Sie im Umgang mit dem Produkt und bei der Montage niemals Gewalt oder hohe Kräfte an.

2.1 Montage

- Fädeln Sie die Klemme auf das Ratschenband wie abgebildet (A) auf.
- Führen Sie das Ratschenband um den Lenker herum und durch den Ratschenkopf.
- Legen Sie zur Schonung des Lenkers die mitgelieferte Gummiauflage zwischen Lenker und Ratschenband und ziehen das Ratschenband lose an (B).
- Nutzen Sie zur endgültigen Befestigung den kleinen Hebel (C). Jeder Zug zieht das Ratschenband eine Raste fester.

2.2 Anbringen der Smartphonetasche

- Setzen Sie die Smartphonetasche wie abgebildet (D) ein. Die Smartphonetasche ist sicher befestigt, wenn Sie in der Klemme mit einem deutlichen Klick einrastet.



Hinweis

Prüfen Sie stets den sicheren Sitz des Smartphonehalters.

- Zur Demontage drücken Sie die Entriegelungstasten und nehmen Sie den Smartphonehalter ab.

3. Haftungsausschluss

Die Dirk Rossmann GmbH übernimmt keinerlei Haftung oder Gewährleistung für Schäden, die aus unsachgemäßem Installation, Montage und unsachgemäßem Gebrauch des Produktes oder einer Nichtbeachtung der Bedienungsanleitung und/oder der Sicherheitshinweise resultieren.

Hergestellt für: Dirk Rossmann GmbH
Isernhägener Straße 16
30938 Burgwedel
www.rossmann.de

GB Operating instruction

Thank you for choosing a Ideenwelt product.

Take your time and read the following instructions and information completely. Please keep these instructions in a safe place for future reference. If you sell the device, please pass these operating instructions on to the new owner.

1. Safety Notes

- Use the product for its intended purpose only.
- Protect the product from dirt, moisture and overheating, and only use it in a dry environment.
- When using this product, observe the applicable local traffic laws and regulations.
- Do not drop the product and do not expose it to any major shocks.
- Keep the packaging material out of the reach of children due to the risk of suffocation.
- Dispose of packaging material immediately according to locally applicable regulations.
- Do not modify the product in any way. Doing so voids the warranty.

2. Montage



Warning – Risk of injury

- Do not allow yourself to be distracted by the product, for example when driving a vehicle or operating sports equipment. Always pay attention to the surrounding traffic and your environment.
- The product is not intended for mounting on carbon parts (for example, handlebars). Carbon parts can be damaged by the clamp, break and cause serious accidents and injuries!



Note

- Never apply force when using the product or during installation.

2.1 Mounting

- Thread the clamp onto the ratchet strap as illustrated (A).
- Loop the ratchet strap around the handlebars and through the ratchet head.
- To protect the handlebars, place the supplied rubber pad between the handlebars and ratchet strap, and loosely tighten the ratchet strap (B).
- Use the small lever for final fastening (C). Each movement tightens the ratchet strap up a notch.

2.2 Attaching the smartphone case

- Insert the smartphone case as illustrated (D). The smartphone case is securely fastened when it audibly clicks into place in the clamp.



Note

Keep checking that the smartphone holder is securely seated.

- To remove the smartphone holder, press the release buttons and take it off.

3. Warranty Disclaimer

Dirk Rossmann GmbH assumes no liability and provides no warranty for damage resulting from improper installation/mounting, improper use of the product or from failure to observe the operating instructions and/or safety notes.

Produced for: Dirk Rossmann GmbH
Isernhägener Straße 16
30938 Burgwedel
www.rossmann.de

